


## IMPORTANT!

- Please make sure connections are soldered or use crimp connections.
- Insulate wires properly with heat shrink.
- Always install a fuse for your safety.



## CONNECTION INSTRUCTIONS

- The red (positive) wire is connected to a 11v-28v power system via a switch and a fuse.
- The brown (ground) wire is connected to the ground 0v. South African brown is ground connection. Black cable can be used if preferred.
- The white (strobe enable) wire is connected to ground via a switch. Optional Strobe On/Off function.
- The yellow (strobe sync) wire is connected to the synchroniser. Optional synchronised strobe flash.

## BASIC FUNCTION

Connecting the main connections to power will turn on both navs and strobes. Strobe lights can be turned off by connecting the white wire to ground, on a switch.

Minimum 18 Gauge Tefzel<sup>®</sup> wire to be used.

PROUDLY MADE IN SOUTH AFRICA BY

**CNLighting**  
Aviation Series

## ANY QUESTIONS?

Call our office Mon-Fri 8:30-5:30 on **(+44) 01743 296406** or our assistance mobile on (+44) 07823 555228. You can also email us at [info@smoothaviation.com](mailto:info@smoothaviation.com)